

Sopii: Automerkki ja malli	Vuosimalli	Etuvyö	Takavyö	Sopii: Automerkki ja malli	Vuosimalli	Etuvyö	Takavyö
ISUZU				NISSAN			
Trooper	84-	913-1	913-4	Patrol	81-	913-1	913-5
IVECO				Prairie	84-91	913-3	913-5
35	85-	913-3940		Primera	90-	913-3	913-5
JAGUAR				Silvia	84-89	913-3	913-5
XJ, XJS		913-1	913-5	Stanza	81-86	913-3	913-5
LADA				Sunny	73-	913-3	913-5
Samara	86-	913-3	913-5	Urvan	80-	913-1	
kaikki muut mallit		913-1	913-5	OPEL			
LANCIA				Ascona A, B	70-81	913-1	913-4
Beta	73-79	913-1	913-4	Ascona C	82-86	913-1	913-5
Delta	86-	913-1	913-5	Astra	91-	913-3	913-5
Dedra	90-	913-1	913-5	Commodore	67-82	913-1	913-4
Prisma	87-91	913-1	913-5	Corsa	83-	913-1	913-5
Thema	86-	913-1	913-4	Kadett B	65-73	913-3	913-4
Y10	85-91	913-1	913-5	Kadett C	74-79		
MAZDA				Kadett D	80-84	913-1	913-5
121	88-	913-3	913-5	Kadett E	85-81	913-3	913-5
323 Saloon, Hatchback	79-85	913-1		Manta B	-81	913-1	913-4
323 Estate	79-85	913-1	913-5	Manta B	82-	913-1	913-5
323	86-	913-1	913-5	Monza	78-85	913-1	913-5
626	79-86	913-1		Omega	86-	913-1	913-5
626	87-	913-1	913-5	Record D, E	72-	913-1	913-5
929	74-87	913-1	913-5	Senator	78-85	913-1	913-5
Xedos	93-	913-3	913-5	Vectra	88-	913-3	913-5
MX3/5	90-	913-3	913-5	PEUGEOT			
E2000 van	85-	913-1		104	72-82	913-1	913-4
MERCEDES BENZ				106	91-	913-3	913-5
W115	68-75	913-1	913-4	204	65-77	913-1	913-4
W123	76-85	913-1	913-5	205	83-93	913-3	913-5
W124	85-	913-1	913-5	304	69-80	913-1	913-4
207, 307	77-92	913-3940		305	78-82	913-1	913-4
407	77-85	913-3940		305	83-88	913-3	913-4
MITSUBISHI				305 farmari	78-82	913-1	913-5
Celeste	76-79	913-3	913-4	305 farmari	83-88	913-3	913-5
Colt	78-84	913-1	913-4	306	93-	913-3	913-5
Colt	85-	913-1	913-5	309	86-92	913-3	913-4
Cordia	83-85	913-3	913-5	404	60-75	913-1	913-4
Galant	76-	913-3	913-5	405	87-	913-3	913-5
Lancer	76-82	913-1	913-4	504	68-82	913-1	913-4
Lancer	83-	913-1	913-5	505	79-91	913-3	913-5
Pajero	83-	913-1		604	75-84	913-1	913-4
Sapporo	78-91	913-3	913-4	605	90-	913-3	913-5
Sigma	91-	913-3	913-5	POLSKI-FIAT			
Space Wagon	84-	913-3	913-5	1300, 1500		913-2	913-5
Tredia	83-88	913-3	913-4	125P	75-85	913-2	913-5
NISSAN				Polonez	78-92	913-2	913-5
Bluebird	72-90	913-3	913-5	PORSCHE			
Cabstar	87-92	913-1		924, 928, 944	76-85	913-3	
Cherry	71-86	913-3	913-5	RENAULT			
Laurel	74-90	913-3	913-5	R4, R6	63-82	913-2	
Micra	83-	913-3	913-5	R5	72-80	913-1	913-5
				R5	81-92	913-5	
				R9	82-89	913-1	913-5
				R11	82-89	913-3	913-5

Sopii:				Sopii:			
Automerkki ja malli	Vuosimalli	Etuvyö	Takavyö	Automerkki ja malli	Vuosimalli	Etuvyö	Takavyö
RENAULT				TOYOTA			
R12	69-80	913-2	913-4	Camry	82-	913-3	913-5
R14	77-83	913-3	913-5	Carina I / II	71-	913-3	913-5
R15	71-75	913-3	913-4	Celica	-85	913-3	913-4
R18	79-86	913-3	913-4	Celica	86-	913-3	913-5
R19	88-	913-3	913-4	Corolla	66-82	913-3	913-4
R20	76-83	913-1	913-5	Corolla	83-	913-3	913-5
R21	86-	913-3	913-4	Corona	64-81	913-1	913-4
R25	84-91	913-3	913-5	Cressida	77-87	913-3	913-4
Clio	91-	913-3	913-5	Crown	72-85	913-3	913-4
Espace	88-	913-3		Hi-Ace	70-	913-3	
Fuego	79-85	913-1	913-5	Hi-Lux	74-89	913-3	
Master	90-	913-3940		Land Cruiser	77-	913-1	
Trafic	81-	913-3940		Lite-Ace	79-92	913-3	
				MR2	86-95	913-3	
SAAB							
95, 96, 90, 99, 900, 9000		913-3	913-5	Previa	91-	913-3	913-5
SEAT							
Ibiza	85-92	913-5		Starlet	79-84	913-1	913-4
Ibiza	93-	913-3	913-5	Starlet	85-87	913-1	913-5
Malaga	85-91	913-1	913-5	Supra	86-93	913-3	
Toledo	92-	913-3	913-5	Tercel	79-82	913-3	913-4
SIMCA KTS. TALBOT							
SKODA							
100, 110	70-80	913-3	913-4	Tercel	83-88	913-3	913-5
105, 120	77-90	913-1	913-5	VAUXHALL			
130	84-91	913-1	913-5	Cavalier	81-83	913-1	913-4
Favorit, Forman	94-	913-1	913-5	Chevette	75-80	913-3	913-4
Rapid 135	89-	913-1	913-5	Viktor, Ventora, VX	-78	913-1	913-4
SUBARU							
1800	82-	913-3	913-4	Viva, Magnum, Firenza	-76	913-3	913-4
Justy	87-94	913-3	913-5	VOLKSWAGEN			
Legacy	89-	913-3	913-5	Corrado	88-92	913-3	913-5
Leone	85-	913-3	913-5	Golf I	74-79	913-1	913-4
1800				Golf I	80-83	913-1	913-5
SUNBEAM KTS. TALBOT							
SUZUKI							
Alto	82-91	913-1	913-4	Golf II	84-91	913-1	913-5
Carry	82-92	913-3		Golf III	92-	913-3	913-5
Samurai	85-93	913-1	913-5	Jetta	80-91	913-1	913-5
Swift	86-	913-1	913-4	Passat	-77	913-1	913-4
SA310	84-86	913-1	913-4	Passat	79-80	913-1	913-5
SJ410	82-89	913-1	913-5	Passat	81-	913-3	
SJ413	85-89	913-1	913-5	Polo	76-	913-1	913-5
Vitara	90-	913-1	913-5	Santana	82-85	913-3	913-5
TALBOT							
Avenger	70-79	913-1	913-4	Scirocco	-81	913-1	913-4
Horizon	78-86	913-3	913-5	Scirocco	82-	913-3	913-4
Simca 1100	68-80	913-3	913-4	LT		913-1	
Solara, 1510	79-86	913-3	913-5	T4		913-1	
				VOLVO			
				Kaikki mallit			
				WARTBURG			
				353			