

Installation Manual

NISSAN PATROL 5DR
NIS-PATR-5-A



COMPONENTS INCLUDED



CL-M02 x 8



CL-M05 x 6



CL-T01 x 1




Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



SIDE SHADE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



SIDE SHADE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



SIDE SHADE INSTALLATION



X2

Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



LOAD AREA SHADE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



LOAD AREA SHADE INSTALLATION




x2

Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



LEFT DOOR TAILGATE INSTALLATION




Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



LEFT DOOR TAILGATE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



LEFT DOOR TAILGATE INSTALLATION






X2

Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



RIGHT DOOR TAILGATE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



RIGHT DOOR TAILGATE INSTALLATION



Installation

NISSAN PATROL 5DR
NIS-PATR-5-A



RIGHT DOOR TAILGATE INSTALLATION

